中文

MZ-508 骑行速显音箱PLUS

感谢您购买本产品。使用蓝牙音箱前,请阅读所有安全信息和操作说明。

安全须知

/nwa®

- 阅读所有说明, 并保存起来以备日后参考。
- 请遵循产品操作的所有说明。
- ●请勿将其放置在热源附近。避免靠近散热器、火炉和其它会发热的设备。避免 长期暴露在阳光和高温下。
- ●此音箱有4种模式: BT/TF/CLOCK/骑行模式。
- ●请注意: 当音乐暂停10分钟后, 音箱将讲入时钟模式。 要重新启动音箱, 请按 电源开/关/模式按钮。

○ 扫描二维码下载APP,骑行模式可显示时速





1 COBONT 控制面板和界面 ● (*): 电源开/关/模式: 长按2秒为开/关机: 开机状态短按切换BT/TF模式。 ② ★:增加音量:长按为音量加,短按为下一曲。 ❸ ▶:播放/暂停/配对:在音箱蓝牙连接状态,或TF卡模式下,短按可以播

显示屏的显示方式

------ 100%电量 ■75%电量

- 在SD卡模式时、TF图标为长亮
- ② 在BT蓝牙模式时,BT图标配对与回连为快闪,连接上为长亮
- 6 88:8.8为状态显示: 默认显示24H制时钟,在APP界面添加蓝牙设备后会自动同步校准时钟。 按"▶"2秒进入手动时钟设置模式,单按为分钟/小时的慢闪切换,并配合 "**十**" "**一**" 设置分钟/小时,再单按 "**▷**" 确认。

蓝牙范围: ≤10m

蓝牙版本: V5.0

频率响应: 20HZ-20KHZ

包装内容

- 工作时长: 60%音量连续工作10h • 充电时长: 2-4hr • 待机时长: ≥300hr • 工作电压: 5V/1A
- 放/暂停;在音箱蓝牙连接状态,短按可以接打电话,长按2秒强制断
- 开当前连接,进入蓝牙搜索配对状态。
- ④ 一:降低音量:长按为音量減,短按为上一曲。
- ⑥ 电源接口: DC 5V 1A
- SD卡接口 3 麦克风 10 电池符号 ⑩ 时速/时钟
- - 自行车支架 ● 0.6m USB充电线
- MZ-508主机 • 夹扣

• 额定功率: 8W


防水等级: IP67

• 电池容量: 2200mAh

充电提示

操作指令

长按电源按钮 "()" 2秒,有开机提示音。 开机后,蓝牙图标"★"快闪,音箱讲入 蓝牙配对状态,默认音量80%,每次打 开音箱后都会自动恢复默认音量80%。



在蓝牙播放时插入TF卡则自动切换到TF卡播放模式。

1.低电量时音箱"低电量报警"提示,您需为音箱进行充电

2.充电时,红色指示灯常亮,充满电后红色指示灯熄灭

3.建议对带锂电池产品如不使用时每三个月充一次电。


打开手机或其他蓝牙设备上的蓝牙功能,然后搜索名为MZ-508的音箱。与音 箱连接。

- 1.在手机上搜索MZ-508音箱;
- 2.连接MZ-508音箱:
- 3.诵讨MZ-508音箱播放音乐。



● 步骤3 如何将音箱与新设备连接:


将音箱与设备连接时,您可以长按播放/暂停/配对按钮 "▶" 2秒以切断当前连 接并进入配对状态。然后,蓝牙图标"★"快闪,音箱可以与新设备连接。



蓝牙状态开机自动回联,无连接10分钟进入时钟模式。

支架安装指南

如图1所示,按下支架的 凸起部分, 后再安装支架。



如图2所示,从支架上拧 下螺钉





如果转向轴太细目不能仅用1个防滑垫固定,则可以将垫1和2放入环中,使转向 轴穿过环,然后用螺钉拧紧支架。 如果支架仍然松动,则可以折叠防滑垫2,然 后将防滑垫1和折叠垫2放入环中,使转向轴穿过环,然后用螺钉拧紧支架。

步骤4

安装支架后,您可以将音箱推入支架。听 到咔哒声后, 音箱就安装好了



蓝牙音箱通话功能

- ●接听电话: 当音箱与手机连接时,如有来电,您可以短按播放/暂停/配对按钮 "▶"即可接听。
- ◆ 挂断电话: 当音箱与手机连接时,通话中
- 您可以短按播放/暂停/配对按钮 "▶" 即
- 拒绝通话: 当音箱与手机连接时, 您可以 通过长按播放/暂停/配对按钮 "▶" 来拒

将防滑垫1放入支架的环中,将支架通过环固定到自行车上,然后用在步骤2中 取出的螺钉拧紧支架。



骑行模式

插入SD卡后,音箱将进入TF卡模式,然

可以短按电源按钮 "()" 进入模式切换。

蓝牙音箱连接记忆功能

使用前先扫描二维码,下载手机APP,蓝牙模式状态下打开手机APP,添加蓝

如果设备蓝牙功能开启,打开音箱后,音箱将自动连接到最后一个配对设备。



时速以每1秒钟刷新时速显示

当手机APP连接上音箱时自动切换到时速显示模式88:8.8只显示时速,S慢闪。

手机静止与运动时显示0~120KM时速 当时速达到S 120时,显示屏与APP界面时速表同时快闪并提示注意降低速度。 当音箱在骑行模式下速度显示,要切换时钟显示按下电源按钮 " 🖒 " 。

电子邮件

购买日期

用户姓名

保修记录

保修卡

用户姓名 维修人员签字

合格证

检验员: _____

lnwa® English

MZ-508 Riding speed display speaker PLUS

Thank you for buying this product. Please read all safety information and operation instruction before using the bluetooth speaker.

SAFETY INSTRUCTIONS

- Read all instructions and save them for personal reference in the future.
- Follow all directions for operating the product.
- Do not place it near a heat source. Avoid getting close to radiators, stoves and other heat-generating equipment. Avoid long-term exposure to sunlight and high
- This speaker has 4 modes: BT/TF/CLOCK/riding mode.
- Please note: When the music is paused for 10 minutes, the speaker will enter the clock mode. To restart the speaker, press the power on/off/mode button.
- Scan the QR code to download the APP, the riding mode can display the speed per hour










foreign version

PRODUCT DESCRIPTION

CONTROL PANEL AND INTERFACE



- ①: Power On/Off/Mode: long press for 2 seconds to turn on/off: short press to switch BT/TF mode in power-on state.
- 2+: Increase volume: long press to increase volume, short press to next song.
- Play/Pause/Pair: In the speaker Bluetooth connection state, or in the TF card mode, short press to play/pause; in the speaker Bluetooth connection state, short press to make and receive calls, long press for 2 seconds to forcefully
- previous song.

disconnect the current connection and enter Bluetooth search for pairing status.

- 6 Power/Charge indicator (red light)
- Power Port: DC 5V 1A
- SD Card Slot Speed/Clock

Display mode of the display

- In SD card mode, the TF icon is always on
- 2 In the BT Bluetooth mode, the BT icon pairing and back-connecting will flash quickly, and the connection will be solid.
- 6 88:8.8 is the status display:

The 24H clock is displayed by default. After adding a bluetooth device on the APP interface, the clock will be automatically synchronized and calibrated. Press and hold "D" for 2 seconds to enter the manual clock setting mode, and a single press is a slow flash switch of minutes/hours, and cooperate with "+" "-" to set the minutes/hours, and then single-press ">" to confirm.

· Charging time: 2-4 hours

Working voltage: 5V/1A

Waterproof level: IP67

Battery capacity: 2200mAh

Rated power: 8W

PRODUCT PARAMETERS

- . Working hours: 10h battery life at 60% volume
- Standby time: >300 hours
- Bluetooth range: <10m
- Frequency: 20HZ-20KHZ

MZ-508 speaker

- Bluetooth version: V5.0

PACKAGE CONTENTS

 Speaker clips Speaker holder for bicycles Manual

0.6m usb charging cable X1

- 1. When the battery is low, the speaker "low battery alarm" prompts, you need to charge the speaker.
- 2. When charging, the red indicator light is always on, and the red indicator light is off when it is fully charged.
- 3. It is recommended to charge the product with lithium battery every three months when not in use.

OPREATION INSTRUCTION

Charging tips

Press and hold the power button "(1)" for 2 seconds, there will be a power-on prompt sound. After power-on, the Bluetooth icon "X" flashes quickly, the

speaker enters the Bluetooth pairing state. and the default volume is 80%. Each time the speaker is turned on, the speaker will automatically restore the default volume of

Step 1

Inserting a TF card during Bluetooth playback will automatically switch to TF card playback mode

Step 2


Turn on the Bluetooth function on your mobile phone or other Bluetooth device, and then search for the speaker named MZ-508. Indicator Light Connect with speakers.

- 1. Search MZ 508 speaker on mobile phone: 2. Connect MZ-508 speakers:
- 3. Play music through MZ-508 speakers.

Step 3 How to connect speakers with new equipment

When connecting the speaker to the device, you can press and hold the Play/Pause/

Pairing button ">" for 2 seconds to cut off the current connection and enter the pairing state. Then, the Bluetooth icon " * " flashes quickly, and the speaker can be connected to the new device.



When Bluetooth is turned on, it will automatically reconnect, and it will enter the clock mode for 10 minutes without connection.

INSTALL ATION GUIDE OF HOLDER



• Step 2

As picture 2 shows, screw out the screws from the holder.



Step 3 Put the non-slip mat 1 into the ring of the holder, fix the holder onto the bike through

the ring, and tighten the holder with screw which has been taken out in step 2




If the steering axle is too thin and can not be fixed with only 1 non-slip mat, you can put

mat 1 & 2 into the ring, pass the steering axle through the ring, then tighten the holder with screw. If the holder is still loose, you can fold the non-slip mat 2, and put the mat 1 & folded mat 2 into the ring, pass the steering axlethrough the ring, then tighten the holder with screw.

Step 4

After installing the holder, you can push the speaker into the holder. Upon hearing a click. the speaker is installed well.



 Θ

TEL FUNCTION OF THE SPEAKER

- Answer a call: When the speaker is connected to the mobile phone, if there is an incoming call, you can short press the Play/Pause/Pairing button ">" to answer
- Hang up the call: When the speaker is connected to the mobile phone, you can short press the Play/Pause/Pairing button
- " b" to hang up during the call.
- Reject call: When the speaker is connected to the mobile phone, you can reject. the call by pressing and holding the Play/Pause/Pairing button ">"


CONNECTION MEMORY FUNCTION OF THE SPEAKER

 The speaker will automatically connect to the last paired device, in case that BT function of the device is on, after turning the speaker on.

TF CARD MODE

Riding mode

After inserting the SD card, the speaker will enter the TF card mode, you can short presthe power button "(1)" to enter the mode



Scan the QR code and download the mobile APP before use open the mobile phone APP in the Bluetooth mode, add a Bluetooth speaker, and the APP pushes the display of the speed of 0 to 120 kilometers per hour and the voice report information to the Bluetooth speaker through the mobile phone.



S is speed 0~120 is the speed per hour

Refresh the speed display every 1 second

When the mobile phone APP is connected to the speaker, it will automatically switch to the speed display mode. 88:8.8 only displays the speed per hour, S flashes slowly, and the mobile phone displays 0~120KM per hour when it is stationary and in motion. When the current speed reaches S 120, the display screen and the APP interface speedometer flash simultaneously and prompt attention to reduce the speed. When the speaker displays the speed in the riding mode, press the power button " ()" to switch the clock display.

Warranty records

Warranty card

Name Fault description



Date of purchase

E-mail